

## Constant Temperature and Humidity Chamber

### Standard Series

P51 to P54

Water Cooling Type	Air Cooling Type	Temperature range	Humidity range	Floor Space
<b>NH</b> Type		-10 to 80°C	20 to 95%RH	6.5m <sup>2</sup> 9.7m <sup>2</sup> 16.2m <sup>2</sup> *1
<b>HH</b> Type		-30 to 80°C		
<b>MH</b> Type		-40 to 80°C	10 to 95%RH	
<b>MHH</b> Type		-40 to 100°C 50°C		



### Excellent Series

**EXCELLENT**  
series

High Load Type

P55, P56

Water Cooling Type	Air Cooling Type	Temperature range	Humidity range	Floor Space
<b>EXNH</b> Type		-10 to 80°C	20 to 95%RH	9.7m <sup>2</sup> *1
<b>EXHH</b> Type		-30 to 80°C		
<b>EXMH</b> Type		-40 to 80°C	10 to 95%RH	
<b>EXMHH</b> Type		-40 to 100°C 50°C		



### Integrated Walk-in Series

P56

Water Cooling Type	Temperature range	Humidity range	Floor Space
<b>NH</b> Type	-10 to 80°C	20 to 95%RH	3.0m <sup>2</sup>
<b>MH</b> Type	-40 to 80°C	10 to 95%RH	3.3m <sup>2</sup>
<b>MHH</b> Type	-40 to 120°C		



\* 1. Standard size.

# Constant Temperature Chamber

## Standard Series

P51 to P54

Water Cooling Type	Air Cooling Type	Temperature range	Humidity range	Floor Space
<b>NT</b> Type		-10 to 80°C	-	6.5m <sup>2</sup> 9.7m <sup>2</sup> *1 16.2m <sup>2</sup>
<b>HT</b> Type		-30 to 80°C		
<b>MT</b> Type		-40 to 80°C		
<b>MTH</b> Type		-40 to 100°C 150°C		



## Excellent Series

**EXCELLENT** series

High Load Type

P55, P56

Water Cooling Type	Air Cooling Type	Temperature range	Humidity range	Floor Space
<b>EXNT</b> Type		-10 to 80°C	-	9.7m <sup>2</sup> *1
<b>EXHT</b> Type		-30 to 80°C		
<b>EXMT</b> Type		-40 to 80°C		
<b>EXMTH</b> Type		-40 to 100°C 150°C		



## Integrated Walk-in Series

P56

Water Cooling Type	Temperature range	Humidity range	Floor Space
<b>NT</b> Type	-10 to 80°C	-	3.0m <sup>2</sup>
<b>MT</b> Type	-40 to 80°C		3.3m <sup>2</sup>
<b>MTH</b> Type	-40 to 120°C		



\* 1. Standard size.